

Normatec 3 Pressure Level Values

	(distal)					(proximal)				
1	Zone 1		Zone 2		Zone 3		Zone 4		Zone 5	
	PP	PT	PP	PT	PP	PT	PP	PT	PP	PT
	40	:30	40	:30	40	:30	40	:30	40	:30
2	Zone 1		Zone 2		Zone 3		Zone 4		Zone 5	
	PP	PT	PP	PT	PP	PT	PP	PT	PP	PT
	50	:30	60	:30	60	:30	60	:30	50	:30
3	Zone 1		Zone 2		Zone 3		Zone 4		Zone 5	
	PP	PT	PP	PT	PP	PT	PP	PT	PP	PT
	60	:30	70	:30	70	:30	70	:30	60	:30
4	Zone 1		Zone 2		Zone 3		Zone 4		Zone 5	
	PP	PT	PP	PT	PP	PT	PP	PT	PP	PT
	70	:30	80	:30	80	:30	80	:30	70	:30
5	Zone 1		Zone 2		Zone 3		Zone 4		Zone 5	
	PP	PT	PP	PT	PP	PT	PP	PT	PP	PT
	80	:30	80	:30	80	:30	80	:30	80	:30
6	Zone 1		Zone 2		Zone 3		Zone 4		Zone 5	
	PP	PT	PP	PT	PP	PT	PP	PT	PP	PT
	80	:30	90	:30	90	:30	90	:30	80	:30
7	Zone 1		Zone 2		Zone 3		Zone 4		Zone 5	
	PP	PT	PP	PT	PP	PT	PP	PT	PP	PT
	100	:30	100	:30	100	:30	100	:30	100	:30

PP = Pulsing Pressure (mm/Hg)
 PT = Pulsing Time (:seconds)